

Instructions  
for the  
Setting-up, Operation & Care  
of  
The  
Orthophonic  
Victrola

SPRING MOTOR TYPE

Before using the instrument read these  
instructions carefully.

VICTOR TALKING MACHINE CO.  
CAMDEN, N.J., U. S. A.



©2004 Mulholland Press, Inc.

## *Your Victrola*

Now that you own a Victrola the whole world of music is open to you. There is no kind of music that you may not hear, at will, for the greatest artists in the world record for the Victrola. Everything is yours from the magnificent pageantry of the grand opera to the wild swing of the dance. The opera, the oratorio, the gospel hymn, the musical farce, the popular song, the war song, the military march, the symphony-these come to you in your own home. There is no variety of personal taste and no condition of mind, to which the Victor records will not minister,

The instrument itself will not require any great or expert care. It is carefully constructed, and before leaving the factory, it is subjected to the most rigorous tests. The directions in this book, however, should be read and the book itself preserved, in order that you may become familiar with every part of it.

To obtain the best results, and the unique quality that goes only with Victor products, you should use only Victor records and the Victrola Tungs-tone styli, or Victor steel needles.

records. It is desirable to occasionally give the stylus a partial turn in the needle arm.

The Victor steel needles are made with the utmost care, and each and everyone is polished to a spherical point and fits perfectly in the Victor record grooves. For perfect reproduction and maximum record life we recommend that you use none other than the Victrola Tungs-tone stylus or the Victor steel needle. A new steel needle should be used for each record, as a steel point wears down during the playing.

### **IMPORTANT**


If any part of your Victrola cannot be placed in perfect condition after following the instructions given in this book, consult a dealer in Victor products.

When returning any part of your Victrola to a dealer in Victor products for repair, give the type and serial number of the instrument as found on the name plate, and the motor number stamped on the small plate on the motor frame.



Victor Cabinet Cleaner is recommended for cleaning and polishing your cabinet. This preparation can be used freely without injuring the finish of the cabinet, It is, however, suggested that you follow the instructions printed upon each can. This cleaner can be purchased from any dealer in Victor Products.

compound should not be used. If a record becomes cracked or badly scratched it is best to completely destroy it. Playing a scratched or imperfect record may result in injury to the sound box.

## VI-THE VICTROLA TUNGS-TONE STYLUS AND THE VICTOR STEEL NEEDLE



We recommend that in playing your records you always use the Victrola Tungs-tone stylus, because it is the one ideal reproducing point. The Tungs-tone stylus employs the metal tungsten, which is soft and fibrous, not hard and crystalline. The Victor Company controls by patent, the use of this metal for reproducing points, and while other points have been made imitating the general form of tungs-tone styli, they are invariably of some other material. The Tungs-tone stylus, because of its soft texture will not wear out your records. And it does not have to be changed for each record. Instead of being tapered the Tungs-tone stylus is cylindrical in shape, and of the same width as the record groove. As its tip wears down, the stylus will not, therefore, like a tapered point, tend to crowd the sides of the record groove and thus impair the tone of the music. Its diameter remains the same from first to last. Each Tungs-tone stylus should play from 100 to 300




Re-enterant Horn Type

## PART I-THE VICTROLA AS A MECHANISM

Behind the scenes at the opera; in the console of the pipe organ and in the studio of the master are mechanisms essential to the production of the pageantry; the music or the painting, In the Victrola, likewise, is a mechanism of reproduction-concealed, silent and dependable. To you, as a Victrola owner, an exact scientific knowledge is not necessary. A general understanding may increase your appreciation and enable you to observe the simple rules for keeping your Victrola in the perfect tune in which it was received.

Mechanically, the Victrola is a device for converting recorded sound waves again into sound. The sound waves are recorded in a spiral groove on the face of the disc record.



**Straight Horn Type**

Victor Full Tone steel needle or Full Tone Tungs-tone stylus gives the best reproduction.

(3)-If a sound box noise should develop and if tightening or changing the needle does not eliminate it, and if the noise persists with various records, it is possible that the sound box is injured, or out of adjustment. Take the sound box to a dealer in Victor products for repair.

### DO NOT

(1)-Do not poke at the metal diaphragm with your finger or with a sharp implement. It is tough and durable, but may be injured through abuse.

(2)-Do not leave the sound box down on the turntable when your Victrola is not in use. Turn it back onto the sound box rest.

(3)-Do not drop the sound box onto the record. When starting to play, lower the sound box gently.


### V-CARE OF RECORDS

The records should be kept as free from dust as possible. Gritty dust on the records not only wears out the record rapidly, but causes harsh and unpleasant reproduction. Before playing, it is advisable to brush off the records. A piece of velvet or plush glued to a wooden block forms an excellent record brush. The records should be kept in the envelopes in which they are received, or in record albums provided for the purpose. The paper separators prevent any possibility of injury by contact between the records. It is also inadvisable to stack the records up, one on top of the other without any regard to the sizes. Records should be assorted as to size to be readily accessible. The records should not be exposed to severe heat, and should be cleaned only by brushing with the velvet or plush pad as noted. Soap and water or any other cleaning

Note-Should it at any time be necessary to remove the motor from the motor board, be sure to first remove the indicator hand. To do this, slide the dust cap to one side, remove the dial cover and crystal, unscrew the small nut on the shaft, then lift the spring washer and hand from the shaft.

## LUBRICATION

The parts requiring lubrication are shown in the oiling diagram. Before lubricating, wipe off the motor with a clean cloth dampened with a little kerosene. The proper lubricant required for your Victrola can be secured from any dealer in Victor products, and only Victor products are recommended.



**Turn Back Sound Box**

## SOUND BOX

### Imperfect Reproduction

(1)-A loose needle is a frequent cause of a noisy sound box, hence if your Victrola reproduces improperly see that the needle is securely fastened in its holder.

(2)- If you are using steel needles, put in a new


needle after every record. Using a steel needle more than once injures the record. The Tungs-tone stylus can be used until the reproduction becomes imperfect. The stylus can be removed from the sound box and re-inserted as desired. With care it should play from 100 to 300 records. The

Reproduction, perfect in every detail, is made at will through the medium of the needle, the sound box and the amplifier. The needle traces the sound wave spiral on the rotating record, carrying the mica diaphragm of the sound box with it in sympathetic vibration. In turn, the diaphragm causes the air in the sound box to vibrate, inducing sound waves that are restored, to the quality and approximate volume of the original.

Typical Victrola reproducing and amplifying mechanisms, with the cabinets cut away are shown on Pages 3 and 4. The spring motor beneath the turntable is wound with the winding key, either when the instrument is playing, or silent. On unwinding, the motor rotates the turntable at the constant speed required for perfect reproduction.

The whole mechanism has the simplicity of perfection. Each detail is the result of numberless experiments and tests, certified by satisfactory service in the hands of the public.

Your Victrola should operate for years without trouble, providing the following simple instructions are followed, and in the event of trouble after extended service, your dealer will be able to replace the parts in the original perfect condition.



**Unfasten Crook**

## PART II-SETTING UP

After your Victrola has been unpacked, in accordance with unpacking instructions, it should be placed in operating condition, as follows:



### PART III-PLAYING YOUR VICTROLA

(1)-Put the Victrola Tungs-tone stylus, or a new Victor steel needle in the sound box needle arm as far as it will go and tighten the needle screw firmly. Place the record on the turntable.

(2)-On an instrument having an automatic brake operated by an eccentric groove record it is necessary to swing the taper tube to the outer edge of the record before pulling the brake hand lever forward, Note-When using this type of automatic brake with records which do not have the eccentric groove, it is necessary to operate the brake by hand.

(3)-Now start the motor by pulling the brake hand lever toward the front of the instrument.

(4)-On an instrument having only a hand brake, start the motor by pulling the brake hand lever toward the front of the instrument; reverse the movement to stop the motor.

(5)-After the turntable has revolved several times, and picked up speed, lower the sound box gently on the smooth outside rim of the revolving record. Then carefully push the needle into the sound wave groove.

(6)-On instruments equipped with a radio valve, the horn can be used for either a record or radio reception by turning knob, near the taper tube, to the right or left, as indicated on the dial.

### PART IV-CARING FOR YOUR VICTROLA

Your Victrola will require but little care mechanically. A little lubrication here and there is all that is required; and this attention is only necessary at infrequent intervals.


1st-Swing the taper tube to the right as far as possible, and then holding the turntable in both hands drop it over the spindle.

2nd-See that slot in the turntable hub drops over the pin in the spindle.


(6)-Next mount the sound box on the sound box crook. The small projection on the inside of the sound box is slipped into the slot in the sound box crook, and is then turned to the right as far as possible, to lock it in place. The stylus, or needle should rest at an angle of about 68° to the surface of the record.

(7)- The winding key may be next inserted in the opening at the right in the cabinet, and the motor wound by turning the key clockwise. A drop of oil should be placed on the escutcheon before inserting the key.


(8)-Wind up the motor by turning the key slowly. Do not wind the spring too tightly. Start the motor by pulling the brake lever towards the front of the cabinet.




**Mount Sound Box**




**Correct Needle Angle**




**Starting**



**Check R. P. M.**



**Lid Support**



**Insert Needle**

(9)-Wind the motor and let it run down two or three times to assure free working of all parts and re-distribution of lubricant. The turntable should revolve at 78 revolutions per minute, by the speed indicator. The speed of revolution may be checked by placing a piece of white paper under the edge of the record on the turntable, and while the sound box and needle are in playing position, note the number of revolutions per minute. The speed regulating screw may be set to give the proper speed.


When this has been done on instruments having a speed indicator, if the indicator hand does not point to 78 on the dial, stop the motor, and remove the turntable. This will allow the motor to run; and while the motor is running slide the dust cap to one side to expose the hand, insert a small screwdriver in the slot in the end of the shaft to hold it in position, then carefully move the hand to the right or left until it points to 78 on the dial.

(10)-On an instrument having


a lid support of the pneumatic cushion type which permits the lid to drop slowly after being released from the catch, the lid should close quietly, but, if it does not, the lid support may require adjustment. After removing the motor board, the adjustment should be made as follows:

1st- If the lid closes with a bump loosen lock nut "A," and turn the adjusting screw "B" to the right until proper cushioning has been secured. Then tighten the lock nut. If, after making the adjustment, the lid fails to operate properly, place a few drops of oil (preferably Neat's-foot) in the top of lid support tube.


2nd- If the lid closes too slowly or does not close tightly, first insert a small wire or any small pointed metal implement into the air vent. This will remove any dirt that may be clogging the vent. After cleaning the vent, if proper action is not obtained, proceed as directed in paragraph one, only turning the adjusting screw to the left. Your Victrola is now ready to play.



**Lower Sound Box**



**Remove Key, Turntable, Motor Board Screws**



**Swing Taper Tube, Lift Motor Out**